





Easy Message (NTCIP models only)

The Easy Message option is the quickest and most efficient way of creating a message and displaying it.



Once logged into the MVMS Control Console, to access the "Easy Message" press <8> at the main menu and you will be prompted with Easy Mode Editing Option screen.

Your cursor will be flashing in the message box and you will be able to type your message navigate the message using the cursor keys. To add another page press <PAGE DOWN>.

When you have finished your message press <F2> Display wait for a message to say "Message Activated". Please note, if you have entered too many characters on a line you will receive an error which indicates this.

Edit the message and then continue. When the message is completed escape (press <ESC>) to the password screen and your message will be displayed.

Quick Step Programming (Only applies to MVMS with Quick Step (QS) Controller)

- 1 Press the **Enter** button on your keyboard and enter your six letter password (default password is vermac). This will take you to the main menu.
- 2 Press <2> **Edit Messages**.
- 3 Press **Enter** while the arrow is aligned with <1> **Messages**.
- 4 Press the down arrow <↓> to access "Number; and hit **Enter** to change your desired message number (message numbers can be programmed 1-80). Press **Enter** to confirm.
- 5 Press <F1> **Edit**, if you would like to create or change a message.
- 6 The cursor is now flashing on the upper right side of your message. You may now type in your first message.
If you would like to add another page hit **Page Down** on your keyboard.

Note: the bottom right corner of the screen will indicate your page number: PG 02/02 (page two of two) and your message number C001 (mess number 1).

AUCKLAND

8 Hotunui Drive
Mt Wellington
PO Box 14111
Panmure, Auckland
Phone 09 259 2600
Fax 09 259 2610

WELLINGTON

26 Cashew Street
Grenada North
PO Box 13351
Johnsonville, Wellington
Phone 04 232 3774
Fax 04 232 3776

CHRISTCHURCH

14A Hillview Road
Phillipstown
PO Box 10036
Phillipstown, Christchurch
Phone 03 366 0512
Fax 03 366 0515

INVERCARGILL

200 Bond Street
Invercargill
PO Box 313
Invercargill
Phone: 03 211-0300
Fax 03 214 1711





Quick Step Programming Cont..

- 7 When you are done entering your message press <F2> **Ok**. Another screen will appear indicating that you have saved a new message successfully. Press **Esc** if screen does not change.
- 8 Return to the main menu by pressing **Esc** twice. While in the main menu press <1> **Display a Message**.
- 9 Select the type of message you would like to display by hitting **Enter** while the arrow is pointing to "TYPE".
Note: The <↑> arrow will select the PERMANENT message group and the <↓> arrow will select the CHANGEABLE
When you want to use the pre-programmed from 001 to 245 you must use "PERMANENT"
When you are using the user messages from 1 to 80 you must use "CHANGEABLE" (Since you are creating your own you will use "CHANGEABLE".)
- 10 Select the message number you would like to use (created in Step 6).
Move the cursor to "Number=1", using the <↓> arrow, and press **Enter**.
Enter the message number from 1 to 80 which you would like to display and press **Enter**. When you are done hit the <F2> **Ok** button to accept.
- 11 You must hit **Esc** twice to return to the main menu. **Note:** For further information on programming the VMS refer to the "Centralo" instruction manual.

AUCKLAND

8 Hotunui Drive
Mt Wellington
PO Box 14111
Panmure, Auckland
Phone 09 259 2600
Fax 09 259 2610

WELLINGTON

26 Cashew Street
Grenada North
PO Box 13351
Johnsonville, Wellington
Phone 04 232 3774
Fax 04 232 3776

CHRISTCHURCH

14A Hillview Road
Phillipstown
PO Box 10036
Phillipstown, Christchurch
Phone 03 366 0512
Fax 03 366 0515

INVERCARGILL

200 Bond Street
Invercargill
PO Box 313
Invercargill
Phone: 03 211-0300
Fax 03 214 1711

